

REPAIR INSTRUCTIONS FOR PVC TUBES

WARNING – HAZARDOUS MATERIALS.

Both alcohol and glue are solvents so appropriate precautions must be taken with their use. We strongly advise that you work in a well-ventilated area, wear protective equipment such as goggles & mask and avoid smoking / naked flames. Please also seal and store materials in a cool, dry place away from risk to children and pets.

1. Using a WHITE cloth, clean the area well with an alcohol-based grease remover. Allow boat to dry thoroughly.
2. Cut out the patch shape and use a pencil to draw around the outline on the boat's surface.
3. Spread glue evenly over both the patch and the repair surface up to the pencil marking.
4. Allow glue to dry for 2 minutes then repeat with a 2nd coat. If it's a cold day, use a hair dryer on a LOW HEAT to dry the glue.
5. Now press patch onto surface and ease out any bubbles. DO NOT remove patch to reposition.
6. Wait 12 hours before use or wetting area.